



General notes and installation tips:

- 1. This race airbox kit installation requires complete removal of bike's PAIR and tank ventilation systems; upmap mapping will care about both solenoids electronic deactivation with no need of dummy plugs.
- 2. Engine wiring loom also needs removal from its plastic runner and relocation. If you are installing the "RAM-AIR KIT" as well, also the vehicle wiring loom must be relocated, please refer to ram-air kit for it. Keep both loom separated anyway, it will come handy at any future engine removal.
- 3. Ignition connectors must be moved on the side of the airbox.


- 4. The airbox comes pre-assembled in its main components; spare top oring and front gaskets are also provided.
- 5. In this "open top" configuration the fuel tank underneath became the airbox lid: it must be clean and smooth. If painting is too rough, use some wet sand-paper on it. Top o-ring and tank internal must be cleaned than greased/lubed at every installation.
- 6. Airfilter is in 3 parts, installation order is: blue foam -> black grid steel frame. For the correct orientation of the parts look at the red dots on the first two, and the notch on the frame (FIG 1).
- 7. Install the temperature sensors pointing down as pictured in FIG 2.
- 8. Install the the front middle support on top of valve cover using the supplied screw and bushing. Remember to put in between the loom ground terminal (FIG 3). Lubricate a bit the section of o-ring glued on top of the support.
- 9. Slide the airbox in the frame, starting from the front, than pushing down the rear till it seats on the throttle body. ATTENTION: stop! if you feel it needs to much force to reach it's final position, and inspect the front airbox mouth: it may collide with frame braces: proceed with braces light grinding till ensure no contact and a trouble free airbox installation, usually the frame casting is not very precise there.
- 10. Install intake stacks Install the MAP sensor and engine vent hose as pictured in FIG 4.
- 11. Place the previously clean, smoothed and lubricated tank (as per 5.) on the airbox, and make it fit. Remove and inspect the seal trace left on the grease/oil: it must be regular and continue all around. Rear corners are the harder spots; you can adjust the o-ring gasket till reaching the better possible seal.

OPTIONAL LID

- 12. The "open top" setup only works on stock OEM fuel tank. For the use of the airbox with aftermarket large capacity aluminium-made fuel tanks you can buy and install an optional lid/cover.
- 13. Remove the standard 10mm o-ring seal fitted to the airbox top and replace it with the 6mm one supplied with the optional lid. Spot-glue it in place using super-glue and lubricate it.
- 14. Slide the lid in the airbox at front than press it down on the seal. Use the 4x supplied self-taping crews to secure it in place.
- 15. Place the aluminium tank in place and check for clearance with airbox.
- NOTE: even with the lid fitted, is it possible to install the OEM fuel tank


ATTENTION:

<u>this is a race product intended to be used on closed courses.</u> <u>ATTENTION:</u> <u>supplied air filter is not efficient on sand and dust: use only in "clean"</u> environment. Inspect and clean often the filter and the airbox internals











Follow us over Facebook and Instagram! Search for @aspecialparts @gabroracing Place our stickers on your bike, post pics on socials and tag us! We will be glad of any product review!